CLAMSHELL FOR GAMBER-JOHNSON UNIVERSAL USB-C DOCKING STATION

USER GUIDE

| Description	Part Number
Clamshell For Gamber-Johnson Universal USB-C Docking Station	AS7.C100.020

ASSEMBLY STEP 1

- Remove handle and two screws shown below to detach the rotation plate

ASSEMBLY STEP 2

- Install and tighten the center bolt on the rotation plate based on what size tablet is being used.

These holes for 12.9"

These holes for 10.9"

ASSEMBLY STEP 3

- Connect the rotation plate to the dock using the 4 provided flat head screws and secure cables in the locations shown below.

ASSEMBLY STEP 4

- Re-install the rotation plate to the mount with the supplied hardware as shown below

ASSEMBLY STEP 5

- Loosen the handle and raise the dock until it is in the upper most portrait position. Ensure the cables are not pulled tight and secure with cable ties as shown below.

Some slack in cables

Upper most portrait position

OPERATION

- With the rear handle loosened, raise the dock all the way to the top of travel, rotate to desired position, lower dock the bottom of travel and tighten handle